

Electronic Circuits

Prof. Nizamettin AYDIN

naydin@yildiz.edu.tr

<http://www.yildiz.edu.tr/~naydin>

Dr. Gökhan Bilgin

gokhanb@ce.yildiz.edu.tr

1

Other Two-Terminal Devices

Schottky diode
 Varactor diode
 Power diodes
 Tunnel diode
 Photodiode
 Photoconductive cells
 IR emitters
 Liquid crystal displays
 Solar cells
 Thermistors

2

Schottky Diode

Also called **Schottky-barrier**, **surface-barrier**, or **hot-carrier** diode.


Characteristics

(Compared with general-purpose diodes)

- Lower forward voltage drop (0.2-.63V)
- Higher forward current (up to 75A)
- Significantly lower PIV
- Higher reverse current
- Faster switching rate

Applications

- High frequency switching applications
- Low-voltage high-current applications
- AC-to-DC converters
- Communication equipment
- Instrumentation circuits




3

Varactor Diode

Also called a **varicap**, **VVC** (voltage-variable capacitance), or **tuning diode**.

It basically acts like a variable capacitor.



4


Varactor Diode Operation

A reverse-biased varactor acts like a capacitor. Furthermore, the amount of reverse bias voltage determines the capacitance. As V_R increases the capacitance decreases.

$$C_{T(VR)} = \frac{C(0)}{(1 + |V_R/V_T|)^n}$$

where

$C(0)$ = the capacitance with no reverse bias applied
 $n = 1/2$ for alloy and $1/3$ for diffused junctions
 V_T = maximum reverse bias voltage
 V_R = applied reverse bias voltage



5

Varactor Diode Applications

FM modulator
 Automatic-frequency-control devices
 Adjustable bandpass filters
 Parametric amplifiers

6


Power Diodes

- Power diodes used in high-power and high-temperature applications, such as power rectifier circuits, must be rated for power
- Power diodes are sometimes referred to as rectifiers
- They have the same symbol and operation as a general-purpose diode
- Power diodes are physically larger than general-purpose diodes, and they require heat sinking.

7

Tunnel Diodes

A tunnel diode has a **negative resistance** region, which means its current decreases as the forward-bias voltage increases.



8


Tunnel Diodes

Operation

The characteristics of the tunnel diode indicate the negative resistance region. Note that this is only a small region of the characteristic curve.

If the forward bias voltage is beyond the negative resistance region, the tunnel diode acts like a general-purpose diode.

If the forward bias voltage is in the negative resistance region then the diode can be used as an oscillator.



9

Tunnel Diode Applications

High frequency circuits
Oscillators
Switching networks
Pulse generators
Amplifiers

10

Photodiodes


A photodiode conducts when light is applied to the junction.

Operation

The photodiode is operated in reverse bias. When light of a particular wavelength strikes the junction it conducts. The higher the intensity of light (measured in foot-candles), the higher the conduction through the photodiode.

Applications

- Instrumentation circuits as a sensor
- Alarm system sensor
- Detection of objects on a conveyor belt



Note that the diode conducts somewhat with no light applied, this is called the *dark current*.

11

Photoconductive Cells


Operation

A photoconductive cell varies resistance with intensity of light.

Like a common resistor, a photoconductive cell has no polarity and can be placed into the circuit in either direction.

Applications

- Light/darkness detection
- Controlling intensity of lighting systems



12

IR Emitters

These are diodes that emit IR (infrared radiation)



Operation

IR emitter produce infrared radiation when forward biased. The higher the forward bias current, the greater the intensity of infrared radiation.

The radiation pattern can vary from widely dispersed to a very narrow, focused beam.

Applications

- Card readers
- Shaft encoders
- Intrusion alarms
- IR Transmitters



13

Liquid Crystal Displays (LCDs)

There are two varieties—those with a light background and dark display or those with a dark background and light display.


Operation

The background is either light or dark, when a voltage is applied to a segment then the alphanumeric display is visible. The amount of voltage necessary for display varies depending on the type of display, from 2 to 20V.

Low power LCDs require less power than LEDs. But LEDs have faster response times and longer life.

Applications

- Digital clocks
- Digital thermometers
- Odometers




14

Solar Cells

Solar cells produce a voltage when subjected to light energy.

The greater the light intensity, the greater amount of voltage produced.



15

Thermistors


Thermistors are resistors whose value changes with temperature.

Operation

Thermistors are negative-coefficient devices—their resistance decreases as the temperature increases.

Applications

- Sensors in instrumentation circuits
- Temperature correction circuitry



16

pnpn Devices

- SCR—silicon-controlled rectifier
- SCS – silicon-controlled switch
- GTO – gate turn-off switch
- LASCR – light-aActivated SCR
- Shockley diode
- Diac
- Triac

17



SCR—Silicon-Controlled Rectifier

The SCR is a switching device for high-voltage and high-current operations.

Like an ordinary rectifier, an SCR conducts in one direction

The terminals are:

- Anode
- Cathode
- Gate



18

SCR Operation


To switch on an SCR:

- Forward bias the anode-cathode terminals (V_F)

AND

- Apply sufficient gate voltage (V_{gate}) and gate current (I_{GT})

Once an SCR is switched on, it remains latched on, even when the gate signal is removed.



- **Holding current (I_H)** is the minimum required current from anode to cathode
- **Reverse breakdown voltage** is the maximum reverse bias voltage for the SCR

19

SCR Operation

To switch off an SCR:


- Remove the power source the anode and cathode terminals

OR

- Reverse bias the anode and cathode terminals

An SCR cannot be switched off by simply removing the gate voltage.

Commutation circuitry can be used for satisfying either of the conditions for switching off an SCR.




20

SCR Commutation

Commutation circuitry is simply a class of switching devices connected in parallel with the SCR.

A control signal activates the switching circuitry and provides a low impedance bypass for the anode to cathode current. This momentary loss of current through the SCR turns it off.

The switching circuitry can also apply a reverse bias voltage across the SCR, which also will turn off the SCR.



21

SCR False Triggering

An SCR can be forced to trigger conduction under several conditions that must be avoided:


- Excessively high voltage from anode to cathode
- High frequency signal from gate to cathode
- High operating temperature

22


SCR Phase Control

The gate voltage can be set to fire the SCR at any point in the AC cycle.

In this example, the SCR fires as soon as the AC cycle crosses 0V. Therefore it acts like a half-wave rectifier.



In this example, the SCR fires later—at the 90° point—on the positive half-cycle.



23

SCR Applications

In these applications the SCR gate circuit is used to monitor a situation and trigger the SCR to turn on a portion of the circuit.

- Battery-charging regulator
- Temperature controller circuit
- Emergency-lighting system

24

SCS—Silicon-Controlled Switch

An SCS is like an SCR, except that it has two gates: a cathode gate and an anode gate.


Either gate can fire the SCS

- A positive pulse or voltage on the cathode gate
- A negative pulse or voltage on the anode gate

Either gate can switch off the SCS

- A negative pulse or voltage on the Cathode gate
- A positive pulse or voltage on the anode gate

Note: The anode gate requires higher voltages than the cathode gate.



25


SCS

Comparison of the SCR and SCS:

- The SCS has a much lower power capability compared to the SCR
- The SCS has faster switching times than the SCR
- The SCS can be switched off by gate control

Applications

- Pulse generator
- Voltage sensor
- Alarm circuits



Pin Identification

26


GTO—Gate Turn-Off Switch

GTOs are similar to SCRs, except that the gate can turn the GTO on and off.

It conducts only in one direction.

Applications

- Counters
- Pulse generators
- Oscillators
- Voltage regulators



27

GTO



Comparison of the GTO and SCS:

- GTO is a low power device
- The gate signal necessary to fire the GTO is larger than the SCR gate signal.
- The gate signal necessary to turn the GTO off is similar to that of SCS
- The switching rate for turning the GTO off is much faster than the SCR

28

LASCR—Light-Activated SCR

The LASCR is an SCR that is fired by a light beam striking the gate-cathode junction or by applying a gate voltage.



Applications

- Optical light controls
- Relays
- Phase control
- Motor control
- Computer applications

29

Shockley Diode


The Shockley diode conducts once the breakover voltage is reached. It only conducts in one direction.

Operation

The Shockley diode must be forward biased, and then once the voltage reaches the breakover level it will conduct. Like an SCR it only conducts in one direction.

Application

- Trigger switch for an SCR



30

Diac


The Diac is a breakover type device.

Operation

Once the breakover voltage is reached the Diac conducts. The Diac, though, can conduct in both directions. The breakover voltage is approximately symmetrical for a positive and a negative breakover voltage.

Applications

- Trigger circuit for the Triac
- Proximity sensor circuit



31

Triac

A triac is like a diac with a gate terminal.


Operation

When fired by the gate or by exceeding the breakover voltage, a triac conducts in both directions.

Applications


- AC power control circuits

Terminal Identification



32

Triac Terminal Identification




33

The Unijunction Transistor (UJT)

The unijunction transistor (UJT) has two base terminals (B_1 and B_2) and an emitter terminal (E).

The UJT symbol resembles the FET symbol. The emitter terminal is angled as shown.



34


UJT Equivalent Circuit

The **interbase resistance** (R_{BB}) is the total resistance between the two base terminals when $I_E = 0$ A.

The **intrinsic standoff ratio** (η) is the ratio of R_{B1} to R_{BB} when $I_E = 0$ A.

Conduction through the emitter terminal begins when the emitter voltage reaches the firing potential, given as

$$V_P = \eta V_{BB} + V_D$$




35

UJT Negative Resistance Region

After a UJT fires, emitter voltage decreases as emitter current increases.

The **negative resistance region** of operation is defined by the peak point (V_P) and the valley point (V_V).




36

UJT Emitter Curves

The UJT emitter curves show the effect of V_{BB} on UJT firing voltage (V_P).

The higher the value of V_{BB} , the higher the value of (V_P) required to fire the component.




37

Using a UJT to trigger an SCR

The UJT is commonly used as a triggering device for other breakover devices, like the SCR.

The SCR shown is triggered when the UJT emitter circuit conducts.


As the capacitor charges, V_E increases. When it reaches V_P , the UJT fires. The voltage developed across R_2 triggers the SCR.



38

Using a UJT to trigger an SCR

The V_E and V_{R2} waveforms for the SCR triggering circuit (below) are shown.




39

The Phototransistor

The phototransistor is a light-controlled transistor. The current through the collector and emitter circuits is controlled by the light input at the base.


The collector current is the product of the transistor current gain (h_{fe}) and the light induced base current (I_L).

$$I_C = h_{fe} I_L$$



40

Phototransistor IC Package



41

Opto-Isolators

Photodiode




Photo-Darlington

Photo-SCR


42

PUT—Programmable UJT

Characteristics

In some of its operating characteristics, a PUT is more like an SCR.

Like the UJT, the PUT has a negative resistance region. But this region is unstable in the PUT. The PUT is operated between the on and off states.




43

PUT Firing

Reducing or removing the gate voltage does not turn off the PUT. Instead, like an SCR, the Anode to Cathode voltage must drop sufficiently to reduce the current below a holding level.

The gate voltage required to turn the PUT on is determined by external components, and not by specifications of the device as in the η value for the UJT.

$$V_G = \frac{R_{B1}}{R_{B1} + R_{B2}} V_{BB} = \eta V_{BB}$$



44